

AutoMat & MiniBar

Bruksanvisning Matlådevärmare

Anslutning

Ugnen ansluts normalt till cigarettändaruttaget. Fordon med 24 volts el-system kan liksom båtar, husvagnar, traktorer etc. sakna tändare. Då användes istället sladdlampsuttag typ Bosch och Hella. Uttaget skall avsäkras med en 10 amp säkring. Hankontakten är av combityp och kan användas till de flesta förekommande typer av uttag.

Användning

Uppvärmningstiden varierar beroende på hur mycket och vad för slags mat som skall värmas. Normalt gäller 30-60 minuter. Då motorn är avslagen bör ugn med en låda vara inkopplad max. 2 timmar, ugn med två lådor max. 1 timme. (Under den kalla årstiden måste dock hänsyn tas till batteriets kondition och utetemperatur.) Efter den tiden bör motorn startas så att batteriet kan laddas. Tag alltid för vana att ställa in matlådan INNAN strömmen kopplas till – och att bryta strömmen INNAN lådan tas ur ugnen. Det spar batteriet och minskar risken för att man glömmer att stänga av ugnen. Ugnen skall inte användas utan att matlåda med mat finns i matdosan, eftersom detta kan medföra skador.

Matlåda och ugn skall rengöras efter användning och behov.

Fastsättning (gäller endast AutoMat)

Skall ugnen monteras fast användes lämpligen de M5 skruvar som följer med. Avståndet mellan ugnens fötter är på AutoMat typ 750 = 115 mm på längden och 70 mm på bredden. På AutoMat typ 1500 = 115 mm resp. 180 mm. Begränsade utrymmen i personbilar gör att bagageutrymmet ofta är den bästa platsen för en värmeugn, oavsett om den är fast monterad eller ej.

För ugn med två fack, var noga med att se till att rätt fack är inkopplat, om bara en låda skall värmas! Ugnen har inbyggd kontrollampa i strömställaren som lyser när ugnen är på. (Gäller endast AutoMat).

OBS! Säkring på 10A finns i stickproppen.



Då stickproppen apteras i cig. uttaget skall den rörliga delen skjutas tillbaks så mycket det går.

Garantisedel

AutoMat typ 750/1500 och MiniBar typ 111/112

För denna produkt lämnar vi 1 års garanti. Felaktig produkt skall med betald frakt åtföljd av denna garantisedel insändas till inköpsstället.

Garantin gäller fabriktions- materialfel.

Skador som uppkommer genom felaktig skötsel ersättes ej.

Garantisedeln är gällande endast under förutsättning att den är fullständigt ifyllt med datum samt underskrift.

Såld den:

Såld av: (Firmastämpel)

No mission is impossible. sepab.se

AutoMat & MiniBar

Instruction for Use – Food Box Heater

Connection

The oven is normally connected to a cigarette lighter outlet. Vehicles with 24V electric systems such as e.g. boats, motor homes and tractors, may not have a lighter outlet. In that case a portable lamp, of the Bosch and Hella type, can be used instead. The outlet must be equipped with a 10A fuse. The male contact is of a combination type and can be used on most existing types of outlets.

Usage

The time to heat varies depending on how much and what kind of food is being heated. Normally, 30 – 60 minutes applies. When the engine is turned off, an oven containing a single food box should be turned on for a maximum of 2 hours. An oven containing two food boxes should be turned on a maximum of 1 hour. (During the cold season of the year, consideration must be given to the condition of the battery and the outside temperature.) After the indicated periods of time, the engine should be started to ensure that the battery can reload. Always make a habit of placing the food box in the oven BEFORE switching on the electricity and removing the food box from the oven BEFORE switching off the electricity. This saves the battery and reduces the risk of forgetting to shut off the oven. The oven must not be used without a food box being placed in the food compartment, since this may result in damages.

The food box and oven must be cleaned after use and when necessary.

Mounting (applies only to AutoMat)

If the oven is to be firmly mounted, it is most suitable to use the M5 screws included in delivery. The distances between the feet are:

AutoMat type 750: 115 mm in length and 70 mm in width.

AutoMat type 1500: 115 mm in length and 180 mm in width.

Limited space in personal vehicles often results in the boot space being the best place for a heating oven, regardless of it being mounted or not.

For two-compartment ovens, make sure that the right compartment is coupled if only one box is being heated! The oven has a built-in control lamp in the electronic switch which will light when the oven is turned on. (Applies only to the AutoMat).



NOTE! The plug has a 10A fuse.

When fitting the plug into the cigarette outlet, make sure the moveable part is pushed backwards as far as possible.

Warranty slip

AutoMat type 750/1500 and MiniBar type 111/112

We offer a 1-year warranty for this product. A faulty product must be returned, transport paid, to its place of purchase together with this warranty slip.

This warranty applies to manufacturing/materials defects only.

Damages arising through inadequate care will not be reimbursed.

This warranty slip is only valid under the prerequisite that it is completed fully, dated and signed.

Sold on:

Sold by: (Company stamp)

No mission is impossible. **sepab.se**