



AutoMat & MiniBar

Bruksanvisning – Matlådevärmare

Anslutning

Matlådevärmaren ansluts normalt till cigarettändaruttaget, eller till annat uttag som passar matlådevärmarens stickpropp. Uttaget skall vara avsäkrat med en 10A säkring. Matlådevärmarens stickpropp är av en kombinations-typ och kan användas till de flesta förekommande typer av uttag.

OBS! Se till att matningsspänningen i uttaget stämmer överens med den spänning som matlådevärmaren är avsedd för (12V eller 24V).

Användning

Uppvärmningstiden varierar beroende på hur mycket och vad för slags mat som skall värmas. Normalt gäller 30 – 60 minuter. Då motorn är avslagen bör matlådevärmare med en låda vara inkopplad max. 2 timmar, och matlådevärmare med två lådor max. 1 timme. Under den kalla årstiden bör även hänsyn tas till batteriets kondition och gällande utetemperatur.

Efter ovan nämnda tid bör motorn startas så att batteriet kan laddas. Tag alltid för vana att ställa in matlådan INNAN strömmen kopplas in, och att bryta strömmen INNAN matlådan tas ur. Detta spar batteri och minskar risken för att man glömmer stänga av matlådevärmaren. Matlådevärmaren får inte användas utan matlåda med mat, annars finns risk för skador.

Matlåda och matlådevärmare skall rengöras efter användning och vid behov.

Fast montering (gäller endast AutoMat)

Skall matlådevärmaren monteras fast så användes lämpligen de bifogade M5-skruvarna. Avståndet mellan ugnens fötter är:

AutoMat, typ 750: 115 mm på längden och 70 mm på bredden.

AutoMat, typ 1500: 115 mm på längden och 180 mm på bredden.

Begränsade utrymmen i personbilar gör att bagageutrymmet oftast är den bästa platsen för en matlådevärmare, oavsett om den monteras fast eller ej.

För matlådevärmare med två fack, var noga med att se till att rätt fack är inkopplat om bara en matlåda skall värmas. Strömställaren har en inbyggd signallampa som lyser när matlådevärmaren är tillslagen (gäller endast AutoMat).

OBS! Stickproppen har en inbyggd, utbytbar, säkring på 10A bakom den blå hatten.





AutoMat & MiniBar

Instructions for Use – Food Box Heater

Connection

The oven is normally connected to a cigarette lighter outlet, or to other outlets supporting the plug. The outlet must be fused with a 10A fuse. The male contact of the oven plug is of a combination type that can be used on most existing type of outlets.

NOTE! Please make sure that the voltage from the outlet corresponds to the voltage that the oven is intended for (12V or 24V).

Usage

The time to heat the food varies depending on how much and what kind of food that is being heated. Normally, 30 – 60 minutes applies. When the engine is turned off, an oven containing a single food box should be used for a maximum time of 2 hours. An oven containing two food boxes should be used for a maximum time of 1 hour. During the cold season of the year, it is also necessary to take into account the condition of the battery and the ambient temperature. After the above indicated periods of time, the engine should be started to ensure that the battery can be charged. Always place the food box in the oven BEFORE the oven is switched on, and always switch off the oven BEFORE removing the food box. This saves the battery and reduces the risk of forgetting to shut off the oven. The oven must not be used without a food box with food in the food compartment. Otherwise, there is a risk of damages.

The food box and oven must be cleaned after use, and when necessary.

Fixed mounting (applies only to AutoMat)

If the oven is to be mounted fixed, the included M5-screws should be used. Distances between the oven feet are: AutoMat, type 750: 115 mm in length and 70 mm in width.

AutoMat, type 1500: 115 mm in length and 180 mm in width.

The limited space in cars often makes the luggage compartment the best place for a heating oven, whether it is being fixed or not.

For ovens intended for two food boxes, please make sure that the right compartment is turned on if only one food box is being heated. The switch has a built-in control lamp which will light when the oven is turned on. (Only applies to AutoMat).

NOTE! The plug has an internal, replaceable, 10A fuse behind the blue cap.

